WARNING:

THIS UPDATE IS FOR THE <u>SUPER PAC-MAN</u> ARCADE1UP ONLY. <u>DO NOT</u> APPLY THIS UPDATE TO OTHER ARCADE1UPS. THIS UPDATE WILL DAMANGE OTHER ARCADE1UPS.





HOW TO UPDATE AREA ARE

SUPER PAC-MAN
PC ONLY
Firmware Update



YOU WILL REED

Arcade1Up Super Pac-Man-Duh.






PC with a USB to Micro USB Cable -To connect the Arcade1Up to a PC.

Windows 8 or Above Operating System is required.

Step 1: Download and Unzip Files









Step 2: Install Drivers






Step 3: Load The Build Into Flash Tool





(Continued)







NOW LETS MOVE ONTO YOUR ARCADE MACHINE




Step 4: Preparing Your Arcade














Step 5: Begin Flashing Process



Connect USB Cable into USB Slot on the PC



At the bottom of your Flash Tool, the status should have changed from "No Devices Found" to "Found One MASKROM Device."





To begin flashing click "RUN" on your flash tool








Step 6: APP Doing Its Thing





THIS UPDATE IS FOR THE SUPER PAC-MAN ARCADE1UP ONLY. DO NOT APPLY THIS UPDATE TO OTHER ARCADE1UPS. THIS UPDATE WILL DAMANGE OTHER ARCADE1UPS.


Step 7: Last Steps




Return to your SUPER Pacman Arcade Machine

Unplug the Micro USB Cable

Flip Flash switch to On position



Plug the 12v Power Cable into the power port





Step 8: The End



Dont forget to replace the back panel of the arcade machine



Power on your Super Pacman Arcade



